

CI-B 2 Primary Supporting Members to be Considered for the Flooding Check

(Mar.
2013)

Rule Section

CSR-BC	Ch. 6, Sec. 4, [1.6.1]	Flooding check of primary supporting members / General
CSR-BC	Ch. 6, Sec. 4, [5]	Flooding check of primary supporting members

Description

The purpose of this interpretation is to provide a unified understanding of the scope of application of flooding check of primary supporting members introduced in the 2012 edition of the CSR for Bulk Carriers.

Common Procedure

In Chapter 6, Section 4 [1.6.1] of the CSR for Bulk Carriers, the flooding check of primary supporting members is requested to be carried out.

The primary supporting members to be considered in this flooding check are those attached to watertight boundaries. Primary supporting members attached to tank boundaries or transverse corrugated bulkheads are not considered in this flooding check since they are checked elsewhere.

The flooding check of Chapter 6, Section 4 [5] only applies to simple primary supporting member arrangements and not grillage arrangements.

Implementation date

This CI is effective from 1 April 2013.

Background

This common procedure has been prepared to provide a unified understanding of CSR for Bulk Carriers.

DOCUMENT HISTORY

ID	Description	Version	Date	Author(s)
01	Initial release by CSR PT1, for circulation to Hull Panel	1.0	28 February 2013	CSR PT1
02	Modification of Format, for circulation to Hull Panel	1.1	28 February 2013	HP Sec
03	Modifications based on Hull Panel Review, for circulation to Hull Panel	1.2	18 March 2013	HP Sec
04				

DISTRIBUTION

ID	Description
01	Initially IACS Internal use only
02	Initially IACS Internal use only
03	Initially IACS Internal use only
04	

STATUS OF DOCUMENT

Author	CSR PT 1	28 February 2013
Accepted		
Accepted		
Accepted		
Accepted		