
GC2 Interpretation of the second sentence of (1977) paragraph 13.2.1

The second sentence of paragraph 13.2.1 reads as follows:

'Where only one level gauge is fitted it should be arranged so that any necessary maintenance can be carried out while the cargo tank is in service.'

In order to assess whether or not only one level gauge is acceptable in relation to the aforesaid sentence, 'any maintenance' means that 'any part' of the level gauge can be overhauled while the cargo tank is in service.

